

The ATN Genoa Sleeve

To install the ATN Genoa Sleeve:

- 1/ furl the genoa tightly.
- 2/ attach the spinnaker halyard to the head of the genoa sleeve.
- 3/ close the genoa sleeve around the furled headsail with the zipper and close the safety lock.
- 4/ fasten the zipper' slider pennant on the life line.
- 5/ hoist the genoa sleeve until the genoa sleeve leaves the deck.
- 6/ fasten the bottom of the genoa sleeve to the top of the roller furler drum with the hank.
- 7/ the slider of the zipper will stop at the genoa sheets.
- 8/ engage and slide the bottom zipper slider up to the genoa sheets.
- 9/ pull on the tightening lines to gather the genoa sleeve:
 start with the double lines, cleat them,
 then pull on the center line, cleat it,
 then put the excess line inside the pocket.
- 10/ close the Velcro straps around the genoa sleeve.

To remove the ATN Genoa sleeve:

- 1/ Slack the spinnaker halyard.
- 2/ Undo the Velcro straps.
- 3/ Uncleat the lines.
- 4/ Pull the ATN genoa sleeve down.

You can watch the video on the website:

<http://atninc.com/atn-genoa-sleeve-sailing-equipment.shtml>