

MagicEzy 9 Second Chip Fix™ Tips & Secrets

Here's how fiberglass is now EZY to fix.

Sure, you need to use a little care to achieve great results. Just follow these steps and repair secrets below and you'll achieve a great durable repair. In fact, we **GUARANTEE** it for 3 years or your money back.

Equipment you'll need

- 9 Second Chip Fix
- Dishwashing detergent
- Water
- Tissue/paper towel

(Optional):

- Hairdryer (for fast drying in cold weather / vertical repairs)
- Damp cloth (for repairs in hot weather)
- Sandwich wrap / clear plastic bag



1. Clean.

Wash damage with dishwashing detergent and water to ensure the surface is free of oil, dirt and grease. Rinse again – this time just with clean water. Ensure all water evaporates or dry the area with a hot hair dryer held one inch away until damage is dry.

REPAIR SECRET: Hot weather application (above 90°F [30°C]) Cool the damaged surface by laying a damp towel before applying 9 Second Chip Fix until the gelcoat is at hand temperature. Keep the area cool by avoiding direct sunlight i.e. use your own shadow to cover the repair.

2. Blend colors (if needed).

Two or more 9 Second Chip Fix colors can be blended together to achieve an appropriate color match. Do not mix other pigments, colorants or additives as this may compromise the adhesion and effectiveness of the product.

REPAIR SECRET: The plastic wrap. Simply mix enough of each colour in some transparent sandwich wrap or plastic bag then place it next to the damage to match the color.

**9 SECOND
CHIP FIX**

MagicEzy

DO IT IN SECONDS



3. Apply and level.

Have a tissue at the ready. Using the MagicEzy tube, apply a ¼ inch (6mm) thick layer into damage.

Turn the tube around and gently smooth the repair with our patented 'LEVEL' on the flat end of tube (see 'arrow'). LEVEL at 90°.

NB: Only a very light touch is required (as if the level is floating on air).

Clean the end of the LEVEL with the tissue.

LEVEL to remove smears around the edges of the repair (but not the repair itself).

Take your time and don't keep touching the repair. Otherwise the repair will look messy.

REPAIR SECRET: Vertical surfaces.

Simply apply 9 Second Chip Fix using the instructions then after the 2nd LEVEL blow a hot hairdryer on the repair for 2 minutes. A skin has now formed and the 9 Second Chip Fix won't slump.

REPAIR SECRET: Deep damage.

A ½ inch deep chip (12mm) can easily be filled by applying 9 Second Chip Fix in ¼ inch layers. The reason for the layers is that all fillers will shrink as they dry. Simply leave time for each layer to dry and shrink before re-applying (overnight is best).

4. Allow to dry.

Leave the repair in the sun to dry for one hour (at 80°F/25°C). It will cure in two hours and be fully cured in one week.

REPAIR SECRET: Cold weather drying.

Temperatures below 20°C-70°F require drying by a hot hair dryer on the surface at 2 inches or 50mm for 2 minutes.

REPAIR SECRET: Achieving a gloss finish.

Even though 9 Second Chip Fix has a matte finish you can achieve a gloss look. Simply apply a piece of clear adhesive tape over the repair and leave for a few weeks until fully cured. This compresses the repair and creates a smooth, glossy finish.

Or – coat with MagicEzy Hairline Fix which has an even better gloss finish.

Water resistant: Not suitable for use on surfaces below the waterline.

Do not use below 50°F/ 10°C

To watch a DIY repair video go to www.MagicEzy.com



**9 SECOND
CHIP FIX**

MagicEzy
DO IT IN SECONDS

