



APPLICATION NOTE - SR005

Accelerating Dry Times

Silent Running is best applied with the ambient, material and substrate temperature in the range of 65 - 85 degrees F.

Low temperatures and high humidity will affect dry times.

To help decrease dry times, the use of low heat indirectly applied to spaces in which Silent Running has been applied and gentle air movement will help speed up the dry time.

High power heaters and fans are NOT recommended.

If there are any question concerning the application of Silent Running, please contact us at the numbers below.

Current Inc.
30 Tyler Street
PO Box 120183
East Haven, CT 06512

Phone: 203-469-1337
Toll free: 877-436-6542
Fax: 203-467-8435