



APPLICATION NOTE - SR007

Bare Wood Application

Silent Running is best applied with the ambient, material and substrate temperature in the range of 65 - 85 degrees F.

When applying to bare wood such as a plywood, the first coat will act as a primer/sealer. It will soak into the wood and disappear. Subsequent coats can then be applied and should be built up to at least a 40 – 50 mil total thickness.

Due to the absorptive properties of the wood, a gallon will probably not make the 30 square foot theoretical coverage number.

So plan accordingly when estimating the amount required, it is better to go a little too thick rather than too thin.

A rough primer coat may be applied in lieu of the first coat of Silent Running. Do not use a finish primer!

If there are any question concerning the application of Silent Running, please contact us at the numbers below.

Current Inc.
30 Tyler Street
PO Box 120183
East Haven, CT 06512

Phone: 203-469-1337
Toll free: 877-436-6542
Fax: 203-467-8435