

## COMPLIANCE

### FCC

FCC 15.21

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC 15.105

This device has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15 Subpart B, of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### IC (ICES-003 ISSUE 6 & RSS-210)

This device complies with industry Canada licence-exempt RSS Standard(s).

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage, et
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### EN

EN301 489-1/-3

EN300 440

EN62368-1


EN62479

EN 60945

**SEADOG<sup>®</sup>LINE**  
QUALITY MARINE GEAR

# BLUETOOTH REMOTE WIRELESS HORN BUTTON

## INSTRUCTIONS



## TECHNICAL DATA

### RECEIVER

Material..... Plastic (ASA)  
 Power Supply..... 12VDC  
 Current..... 20A  
 Frequency..... 2.4 GHz  
 Size (LxWxH)..... 62 x 67 x 32mm  
 Weight..... 100g


### TRANSMITTER

Material..... Plastic (ASA)  
 Battery..... CR2032  
 Frequency..... 2.4 GHz  
 Size (ODxH)..... Ø 56.8 x 23mm  
 Weight..... 35g

## RECEIVER INSTALLATION

### RECEIVER INSTALLATION

1. The receiver should be installed on flat surface in a dry location.
2. Secure receiver with two (2) M4-12mm round head fasteners.




## TRANSMITTER INSTALLATION

**Make sure to remove the battery protection strip when installing the cap.**


### A) SCREW MOUNT

Make sure the horn symbol is lined up correctly when the cap is in place on steering wheel center cap. Holding the base, turn the transmitter cover counter-clockwise and remove the cover. Using two (2) M4-16mm flat head screws, screw base to steering wheel center cap. Put the cover back on and turn clockwise to close. Be sure to close cap tightly.




### B) ADHESIVE MOUNT

Make sure the surface of the transmitter base and steering wheel cap are clean then put the 3M double-side adhesive on the transmitter. Make sure the horn symbol is lined up correctly and attach it to the steering wheel cap. Be sure to close cap tightly.



## ELECTRICAL WIRING

Provide 12VDC input power to the receiver and use 12AWG wire for making the connections. Please note that the typical effective wireless receiving range is around 15 ft. Following the wiring diagram:



## BATTERY REPLACEMENT

1. Turn the transmitter cover counterclockwise and replace the battery with new CR2032 battery.
2. Put the cover back on and turn clockwise to close.

